

# **Operating Instructions DC19B GREEN**

for plastic drums in combination with Cordstrap

# Operating Instructions DRUMCLIP DC19B GREEN

In combination with three Cordstrap CC 65 Composite Strapping (19mm; 3/4"), and three CB 6S Buckle (19mm, 3/4").

The DRUMCLIP DC19B GREEN is an innovative tool that makes it **safer** and **easier** to secure 200-litre plastic drums to a pallet, without the use of additional pallets or other equipment. This solution is ISTA 3 E Pallet Stability and EUMOS 40509 Transport Safe certified. This combination can be used for pallet stabilisation of 200 litre plastic drums on pallets.

#### Important information

- Check the Drumclip before use. A damaged Drumclip may not be used again.
- Check the production date on the upperside of the Drumclip. The Drumclip must not be used for longer than 2 years after the production date.
- The Drumclip can be cleaned with water and soap.
- If the Drumclip has been in contact with chemicals, it may no longer be used.
- Drumclips must be kept in dry, moderately heated conditions and protected from sunlight and mechanical damage.
- The Drumclip may not be dried or stored near fire or in places with elevated temperatures.

## Step 1

Place four plastic drums on a wooden pallet.

## Step 2

Place four Drumclips on the outside of the drums with the wide side facing out. Each Drumclip lies between two drums. Use three Cordstrap CC 65 Composite Strapping and two CB 6S Buckles. One strap is stretched horizontally around the drums. The second strap is stretched vertically over two Drumclips that are opposite each other and under the pallet. The third strap is used to do the same with the other two Drumclips. The Buckle is used to connect the straps. Make sure that the position of the Buckle is not on the outside of the trailer or on top of the drums. For the correct positioning of the Buckle and the tension of the straps we recommend consulting Cordstrap's strapping instructions. Now the pallet is safely certified



according to ISTA 3E Pallet Stability and EUMOS 40509 Transport Safe. The above step should be performed for each pallet with drums.

